

Turkey Sloppy Joes

Ingredients:

1 7½ ounce tube refrigerated buttermilk biscuits
1 tablespoon olive or vegetable oil
1 pound ground turkey
1 8oz jar [Frank's Pickled Peppers Sweet & Spicy Salsa](#)
kosher salt and pepper to taste

Directions

1. Bake the biscuits according to the package directions. Let cool before slicing each biscuit in half.
2. Meanwhile, heat the oil in a skillet over medium-high heat. Add the turkey and cook until no trace of pink remains, about 7 minutes.
3. Season with salt and pepper. Stir in the salsa and cook until heated through, about 2 minutes.
4. Place the bottom halves of the biscuits on a plate. Top with the meat mixture and sandwich with the remaining biscuit halves.

